

POST SCRIPTS

PS 595
JUNE 02

PLGR Fuse NSN Correction

Change the NSN for the PLGR power cable fuse listed on Page 53 of PS 591 from NSN 6150-01-382-1551 to NSN 5920-00-280-4960. The NSN given in PS is for a cable assembly and not a cartridge fuse.

MAP ORDERING UPDATE

Page 61 of PS 586 told you where to go to order maps. We didn't tell you that when you order maps from the National Imagery and Mapping Agency (NIMA), you use your ULLS S-4 DODAAC. If you don't have one, use your unit's PBO DODAAC. You are not authorized a separate DODAAC for maps. The only exception is for *Flight Information Publications* (FLIP). If you need a FLIP DODAAC, contact SFC White at DSN 656-4870, (703) 806-4870, at the U.S. Army Aeronautical Services Agency in Ft. Belvoir, VA.

Need maps? Go to:

<http://www.dscr.dla.mil/pc9/rmf.htm>
or contact the DSCR Richmond Map Facility, 1-800-826-0342, then press 5, or you can call DSN 695-4341. (The address on DLA Form 1832 must match the address on the DODAAC you are using.)

M871A2 RESISTOR KIT

To get a 95-watt resistor kit to handle extra marker lights on your M871A2 trailers, order NSN 5905-01-396-7097. The kit does not replace Item 2 in Fig 7 of TM 9-2330-386-14&P, but it may be needed to power the extra lights. Installation instructions come with the kit.

CIE NSNs ON THE Web

Having trouble finding the NSNs for clothing and individual equipment (CIE)? Check out

<http://ct.dscpc.dla.mil/Ascot>
on the Internet. It lists NSNs for most of the Army's CIE. Before ordering, though, check SB 700-20 to make sure the NSN is authorized for the Army.

ODS Bradley VDB

Need a new vehicle distribution box (VDB), NSN 6110-01-442-8080, for your ODS Bradley? Then make sure you put advice code **2B** in card columns 65-66 of your requisition form. Leave it blank and you might get distribution box, NSN 6110-01-201-7880, as a substitute VDB. That box doesn't have the J20 plug required for the ODS Bradley.

Improved HMMWV Turret Bearing

When the weapon station turret bearing fails on your armored HMMWV, it must be replaced with NSN 3110-01-480-5857. In order to install the new bearing, special repair materials and instructions must be used. A list of materials and the installation instructions are available from TACOM (e-mail mcinernj@tacom.army.mil, DSN 786-2722, (586) 574-2722) or from MSG Half-Mast (e-mail psmag@logsa.army.mil, DSN 645-0893, (256) 955-0893).

New Nuts for MLRS

Switch your MLRS to self-locking nuts with nonmetallic insets on the cab hinge, road-wheels and track pads. They hold better than the ones currently listed in TM 9-1450-646-24P. Use NSN 5310-00-068-8067 for Item 8 in Fig 1 and Item 78 in Fig 171. Use NSN 5310-00-175-2710 for Item 5 in Fig 9, Item 4 in Fig 13, and Items 13, 15 and 21 in the KITS section.

FMTV CRANE CLEVIS CLAMP

Users of M1084/M1084A1, M1086/M1086A1 and M1089/ M1089A1 FMTVs equipped with a crane need clamp, NSN 4030-00-042-7882, to complete TACOM Maintenance Advisory Message 02-018. Read Para (c), Page C-5, of TB 43-0142, *Safety Inspection and Testing of Lifting Devices*, in addition to the MAM, to correctly install the clamps.

AVENGER CAMOUFLAGE NSN WRONG

Don't order the NSN for Avenger camouflage listed on Page 43 in PS 592 (Mar 02). It's not the correct camouflage for the Avenger. The camouflage for the Avenger is radar-transparent camouflage, not radar-scattering. The NSN listed in the article is for the ultra-lightweight camouflage net system (ULCANS), woodland radar-scattering, which currently can't be ordered as a replacement for the lightweight camouflage screen system (LCSS). ULCANS is currently authorized only for initial issue and to replace already fielded ULCANS. To order LCSS camouflage for the Avenger, use NSN 1080-00-103-1322 for woodland radar transparent and NSN 1080-00-103-1217 for desert radar transparent.

DISTRIBUTION: To be distributed in accordance with the initial distribution number (IDN) 340312, requirements for TB 43-PS-Series

Would You Stake Your Life ^{right now} on
the Condition of Your Equipment?